

Installation and service instructions

for contractors

VIESSMANN

Vitodens 111-W

Type B1LA, 6.5 to 35.0 kW

Gas condensing storage combi boiler

Natural gas and LPG version

For applicability, see the last page



VITODENS 111-W



Safety instructions



Please follow these safety instructions closely to prevent accidents and material losses.

Safety instructions explained



Danger

This symbol warns against the risk of injury.



Please note

This symbol warns against the risk of material losses and environmental pollution.

Note

Details identified by the word "Note" contain additional information.

Target group

These instructions are exclusively designed for qualified personnel.

- Work on gas equipment must only be carried out by a qualified gas fitter.
- Work on electrical equipment must only be carried out by a qualified electrician.
- The system must be commissioned by the system installer or a qualified person authorised by the installer.

Regulations

Observe the following when working on this system

- all legal instructions regarding the prevention of accidents,
- all legal instructions regarding environmental protection,

- the Code of Practice of relevant trade associations.
- all current safety regulations as defined by DIN, EN, DVGW, TRGI, TRF, VDE and all locally applicable standards.

If you smell gas



Danger

Escaping gas can lead to explosions which may lead to serious injury.

- Do not smoke. Prevent naked flames and sparks. Never switch lights or electrical appliances ON or OFF.
- Close the gas shut-off valve.
- Open windows and doors.
- Remove all people from the danger zone.
- Notify your gas or electricity supplier from outside the building.
- Shut off the electricity supply to the building from a safe place (outside the building).

If you smell flue gas



Danger

Flue gas can lead to life-threatening poisoning.

- Shut down the heating system.
- Ventilate the boiler room.
- Close all doors in the living space.

Safety instructions (cont.)

Working on the system

- When using gas as fuel, also close the main gas shut-off valve and safeguard against unauthorised reopening.
- Isolate the system from the power supply and check that it is no longer 'live', e.g. by removing a separate fuse or by means of a main isolator.
- Safeguard the system against unauthorised reconnection.



Please note

Electronic modules can be damaged by electrostatic discharges.
Touch earthed objects, such as heating or water pipes, to discharge static loads.

Repair work



Please note

Repairing components that fulfil a safety function can compromise the safe operation of your heating system.
Replace faulty components only with original Viessmann spare parts.

Ancillary components, spare and wearing parts



Please note

Spare and wearing parts that have not been tested together with the heating system can compromise its function. Installing non-authorised components and non-approved modifications or conversions can compromise safety and may invalidate our warranty.
For replacements, use only original spare parts supplied or approved by Viessmann.

Index

Service instructions

Installation information

Product information.....	6
Preparing for the boiler installation.....	7

Installation instructions

Installation sequence

Fitting the wall mounting bracket.....	9
Fitting the boiler and making connections.....	10
Opening the control unit casing.....	15
Electrical connections.....	15

Service instructions

Commissioning, inspection, maintenance

Steps - commissioning, inspection and maintenance.....	19
Further details regarding the individual steps.....	20

Troubleshooting

Function sequence and possible faults.....	38
Fault messages on the display.....	39
Repairs.....	43

Gas type conversion

Converting from LPG to natural gas	52
--	----

Control unit

Functions and operating conditions in weather-compensated mode.....	54
---	----

Designs

Connection and wiring diagram.....	56
------------------------------------	----

Parts lists

Ordering parts.....	58
Overview of the assemblies.....	59
Casing assembly.....	60
Heat cell assembly.....	61
Burner assembly.....	63
Hydraulic assembly.....	65
Aqua plate assembly.....	67
Control unit assembly.....	68
Cylinder assembly.....	70
Miscellaneous assembly.....	71

Index (cont.)

Specification	73
Certificates	
Declaration of conformity.....	74
Keyword index	75

Product information

Vitodens 111-W, type B1LA

Preset for operation with natural gas.


Conversion to LPG P requires a gas conversion kit.

Conversion for other countries

The Vitodens 111-W should generally only be delivered to those countries specified on the type plate. For deliveries to alternative countries, an approved contractor must arrange individual approval on his own initiative and in accordance with the law of the country in question.

Preparing for the boiler installation

Dimensions and connections



- (A) Area for electrical connections
- (B) Heating flow
- (C) Condensate drain
- (D) Heating return
- (E) Filling/draining

- (F) Gas connection
- (G) Safety valve (on the DHW side)
- (H) Cold water
- (K) DHW

Preparing for the boiler installation (cont.)


Preparing the connections

Note

This boiler (IP rating: IP X4D) is approved for installation in wet rooms inside safety zone 1 in accordance with DIN VDE 0100, providing the occurrence of hosed water can be ruled out. Observe the requirements of DIN VDE 0100.


1. Prepare the water connections. Flush the heating system.
2. Prepare the gas connection.
3. Prepare the electrical connections.
 - Power cable NYM-J 3 x 1.5 mm².
 - Accessory cables:
NYM-O two-core min. 0.5 mm².

Fitting the wall mounting bracket



Fitting the boiler and making connections

Removing the front panel and mounting the boiler



1. Undo screws at the bottom of the boiler; do not remove completely.
2. Remove front panel.
3. Hook the boiler into the wall mounting bracket.

Making the connections on the water side




For fittings on the heating water side and DHW side, see separate installation instructions.



Please note

To prevent equipment damage, install all pipework free of load and torque stresses.


Fitting the boiler and making connections (cont.)



- Ⓐ Heating flow
- Ⓑ Heating return
- Ⓒ Gas connection

- Ⓓ Cold water
- Ⓔ DHW

Gas connection



1. Connect gas shut-off valve to connection Ⓐ.



Fitting the boiler and making connections (cont.)

2. Carry out a tightness test.

Note

For tightness tests, use only approved leak detection agents (EN 14291) and devices. Leak detection agents with unsuitable constituents (e.g. nitrites, sulphides) can cause material damage.

Remove residues of the leak detection agent after testing.



Please note


Excessive test pressure may damage the boiler and the gas valve.

Max. test pressure 150 mbar.
Where higher pressure is required for tightness tests, disconnect the boiler and the gas valves from the gas supply pipe (undo the fitting).

3. Vent the gas line.

Fitting the boiler and making connections (cont.)

Condensate drain connection



Connect the condensate pipe (A) with a constant fall and a pipe vent to the public sewage system. Observe the local waste water regulations.

Note

Fill the siphon with water before commissioning.

Filling the siphon with water




Please note

At commissioning, flue gas may be emitted from the condensate drain.

Fill the siphon with water before commissioning.

Fitting the boiler and making connections (cont.)




Fill in at least 0.3 l of water into the flue outlet.



Please note

Water in the ventilation air supply can be detrimental to the combustion quality.
Never pour water into the external vent.

Balanced flue connection




Connect the balanced flue.



Flue system installation instructions.

Opening the control unit casing



Please note

Electronic assemblies can be damaged by electrostatic discharge.

Before beginning work, touch earthed objects, such as heating or water pipes, to discharge static loads.


Electrical connections



Information on connecting accessories

When connecting accessories observe the separate installation instructions provided with them.

Electrical connections (cont.)



- (A) Only for weather-compensated mode:
Outside temperature sensor (accessory)
- (B) OpenTherm device
Remove jumper (D) when making this connection.
- (C) Connecting cable (accessory)
- (D) Jumper

- (E) Power supply (230 V, 50 Hz).
See page 17.
- (F) Vitotrol 100
Remove jumper (D) when making this connection.

 Separate installation instructions

Accessory connection

 Accessory installation instructions

When connecting a Vitotrol 100 or an OpenTherm remote control, remove the jumper across L and 1.

Outside temperature sensor (accessory)

1. Fit outside temperature sensor.

Installation site:

- North or north-westerly wall, 2 to 2.5 m above ground level; in multi storey buildings, in the upper half of the second floor
- Not above windows, doors or ventilation outlets

Electrical connections (cont.)

- Not immediately below balconies or gutters
 - Never render over
 - Connection:
2-core lead, length max. 35 m with a cross-section of 1.5 mm²
2. Plug the power cable supplied with the outside temperature sensor into slot "X21".
 3. Connect the outside temperature sensor to terminals 3 and 4 (see page 16).

Power supply

Regulations and Directives



Danger

Incorrectly executed electrical installations may result in injuries through electric shock and to appliance damage.

Connect the power supply and implement all safety measures (e.g. RCD circuit) in accordance with the following regulations:

- IEC 60364-4-41
- VDE regulations
- Connection requirements specified by your local power supply utility

Install an isolator in the power cable which simultaneously separates all non-earthed conductors from the mains with contact separation of at least 3 mm.

We additionally recommend installing an AC/DC-sensitive RCD (RCD class B ) for DC (fault) currents that can occur with energy efficient equipment. Protect the power cable with max. 16 A.



Danger

Incorrect core allocation can result in serious injury and damage to the appliance. Take care **not** to interchange wires "L1" and "N".



Danger

The absence of component earthing in the system can lead to serious injury from electrical current if an electrical fault occurs. Connect the appliance and pipework to the equipotential bonding of the building in question.

Electrical connections (cont.)


Routing connecting cables and closing the control unit casing



Please note

Connecting cables will be damaged if they touch hot components.

When routing and securing cables/leads on site, ensure that the maximum permissible temperatures for these cables/leads are not exceeded.



Steps - commissioning, inspection and maintenance

For further information regarding the individual steps, see the page indicated

	Commissioning steps	Inspection steps	Maintenance steps	Page
•	•	•	•	1. Filling the heating system..... 20
•	•	•	•	2. Venting the boiler by flushing..... 22
•	•	•	•	3. Changing to operation with LPG..... 23
•	•	•	•	4. Matching the burner output to the flue system..... 23
•	•	•	•	5. Reducing the max. heating output..... 24
•	•	•	•	6. Checking the CO ₂ content..... 26
		•	•	7. Burner removal 29
		•	•	8. Checking the burner gasket and burner gauze assembly..... 30
		•	•	9. Checking and adjusting electrode..... 31
		•	•	10. Cleaning the heat exchanger..... 32
		•	•	11. Checking the condensate drain and cleaning the siphon..... 33
		•	•	12. Burner installation 34
		•	•	13. Checking the diaphragm expansion vessel and system pressure..... 36
		•	•	14. Checking the function of safety valves
•	•	•	•	15. Checking all connections on the heating water side and DHW side for leaks
•	•	•	•	16. Checking flue system for unrestricted flow and tightness
•	•	•	•	17. Checking firm seating of electrical connections
•	•	•	•	18. Checking gas equipment for tightness at operating pressure 36
		•	•	19. Fitting the front panel..... 37
•	•	•	•	20. Instructing the system user..... 37

Further details regarding the individual steps

Filling the heating system




Please note

Unsuitable fill water increases the level of deposits and corrosion and may lead to boiler damage.


- Thoroughly flush the entire heating system prior to filling it with water.
- Only use fill water of potable quality.

- Soften fill water harder than 16.8 °dH (3.0 mmol/l).
- An antifreeze additive suitable for heating systems can be added to the fill water.



1. Close the gas shut-off valve.
2. Switch ON power and wait until the display shows the boiler water temperature.
3. Turn rotary selector "III" fully anti-clockwise, until the display shows "SERV".
Within 2 s return the rotary selector to the r.h. control range.
The display shows "III" and "🔧".
Filling is active.
This function will end automatically after 20 min or after the ON/OFF switch has been turned off.


Further details regarding the individual steps (cont.)



4. Open shut-off valves (A) and (if installed) (B).
5. Connect fill hose to tap (C) and open tap (C).
6. Fill heating system. (Minimum system pressure > 0.8 bar).
7. Close tap (C).

Further details regarding the individual steps (cont.)

Venting the boiler by flushing



1. Close the shut-off valves on the heating water side.
2. Connect the drain hose between top tap (B) and a drain.
3. Open taps (A) and (B) and vent at mains pressure, until no sound of escaping air can be heard.
4. Close taps (A) and (B), open the shut-off valves on the heating water side.

Further details regarding the individual steps (cont.)

Changing to operation with LPG

In the delivered condition, the boiler is set up for operation with natural gas. For operation with LPG, change the gas nozzle and convert the gas type in the control unit.






Separate installation instructions.

Changing from LPG to natural gas - see page 52.

Matching the burner output to the flue system

To match the burner output to the system's flue pipe length, a correction factor can be set.



1. Switch on the ON/OFF switch.
2. Turn both rotary selectors "⏻" and "🔥" simultaneously to their respective central positions.
"SERV" appears on the display.
3. Refer to the following table for the correction factor required for the connected flue system.
4. Within 2 s, turn rotary selector "⏻" into the top left range.
The display shows "III", "⏻", "⏻", and the selected correction factor flashes.
In the delivered condition, factor 0 has been set.
5. Within 15 s, set rotary selector "🔥" to the required correction factor.
6. The set correction factor is saved when the value stops flashing, and the control unit returns to standard mode.

Further details regarding the individual steps (cont.)

Correction factor		1	2	3	4	5	6
Flue system	Rated heating output (kW)	Max. run length (m)					
Open flue operation Ø 60 mm	19	4	10	16	22	—	—
	26	2	8	13.5	18.5	22	25
	35	5	12	18	23	—	—
Balanced flue operation Ø 60/100 mm coaxial	19	2	6	10	13	16	19
	26	1	4	7	10	12	13.5
	35	3	6	9	12	14	17
Balanced flue operation Ø 60/60 mm parallel	19	4	10	16	22	27	32
	26	2	8	13.5	18.5	22	25
	35	5	12	18	23	—	—

Observe max. flue pipe lengths in the pricelist. If the max. flue pipe lengths in the pricelist are exceeded, calculated performance verification is required.

Reducing the max. heating output


The max. heating output can be reduced according to the system requirements.

1. Switch on the ON/OFF switch.

Note


The heating output can only be changed with the burner in operation.

Further details regarding the individual steps (cont.)




2. Turn rotary selector "🌡️ IIII" fully clockwise, until the display shows **"SERV"**.

Within 2 s return the rotary selector to the r.h. control range. The display shows "👁️".




3. Select the required max. heating output with rotary selector "🌡️ IIII". Bars indicating the selected heating output flash on the display.



- Position 1 (1 bar) = lower heating output.
 - Position 6 (5 bars) = upper heating output.
4. Test selected heating output by measuring the gas throughput.

Further details regarding the individual steps (cont.)




5. Transfer selected heating output:
Turn rotary selector "🔥" fully clockwise for less than 2 s and then back into the r.h. control range.
During the transfer, "-.-.-" will be displayed.
6. Shut down the boiler.

Checking the CO₂ content

Note

Operate the appliance with uncontaminated combustion air to prevent operating faults and damage.




1. Connect a flue gas analyser at flue gas port (A) on the boiler flue connection.
2. Start the boiler and check for leaks.




Danger

Escaping gas leads to a risk of explosion.
Check gas equipment for tightness.


Further details regarding the individual steps (cont.)



3. Turn rotary selector "🌡️ III" fully clockwise, until the display shows **"SERV"**.
Within 2 s return the rotary selector to the r.h. control range. The display shows **"P"**.



4. Set to upper heating output:
Turn rotary selector "🌡️ III" fully clockwise, until the display shows 5 bars for the higher heating output.
5. Check the CO₂ content for the upper heating output.
The CO₂ content must be between 7.0 and 10.5 %.




6. Set to lower heating output:
Turn rotary selector "🌡️ III" fully anti-clockwise, until the display shows 1 bar for the lower heating output.
7. Check the CO₂ content for lower heating output.
The CO₂ content must be between approx. 0.3 and 0.9 % below the value for the upper heating output.

Further details regarding the individual steps (cont.)

8. ■ If the CO₂ content is within the given range, continue with point 10.
■ If the CO₂ content is **outside** the given range, check the flue gas/ventilation air system for tightness; remedy any leaks.
Replace gas train if required.
9. Check the CO₂ content for upper and lower heating output again.
10. Shut down the boiler, remove the flue gas analyser and cap flue gas port (A).
11. Turn both rotary selectors "🔧" and "🔧" to their original positions.

Further details regarding the individual steps (cont.)

Burner removal



1. Switch off the power.
2. Shut off the gas supply.
3. Pull power cables from fan motor (A), gas valve (B) and electrodes (C).
4. Push grommet (D) down.
5. Undo gas supply pipe fitting (E).

Further details regarding the individual steps (cont.)

6. Undo four screws (F) and remove the burner.




Please note

To prevent any damage, never rest the burner on the burner gauze assembly.

Checking the burner gasket and burner gauze assembly

Check burner gasket (A) and burner gauze assembly (D) for possible damage and replace, if required.



1. Remove electrode (B).



2. Undo the two Torx screws and remove thermal insulation ring (C).

Further details regarding the individual steps (cont.)

3. Undo two Torx screws and remove burner gauze assembly (D) with its gasket (E).
4. Insert a new gasket (E) and a new burner gauze assembly (D) and secure.
Fixing screw torque: 3.5 Nm.
5. Mount thermal insulation ring (C).
Fixing screw torque: 3.5 Nm.
6. Fit electrode (B).
Fixing screw torque: 4.5 Nm.


Checking and adjusting electrode

1. Check the electrode for wear and contamination.
2. Clean the electrode with a small brush (not with a wire brush) or emery paper.
3. Check the electrode gaps. If the gaps are not as specified or the electrode is damaged, replace and align the electrode together with a new gasket. Tighten the electrode fixing screws with 4.5 Nm.



Further details regarding the individual steps (cont.)

Cleaning the heat exchanger




1. **!** **Please note**
Scratches on parts that are in contact with flue gas can lead to corrosion.
Never use brushes to clean the heat exchanger.

Use a vacuum cleaner to remove residues from heat exchanger (A) inside the combustion chamber.

2. If required, spray slightly acidic, chloride-free cleaning agents based on phosphoric acid onto heat exchanger (A) and let the solution soak in for at least 20 min.
3. Thoroughly flush heat exchanger (A) with water.

Further details regarding the individual steps (cont.)


Checking the condensate drain and cleaning the siphon



1. Release hook and remove siphon (A) with sealing piece (B). Pull siphon (A) upwards away from the drain connection.
2. Remove supply hose (C) from siphon (A).
3. Clean siphon (A).
4. Insert siphon (A) with sealing piece (B). Refit siphon (C) to the drain connection.
5. Refit supply hose (C).
6. Fill siphon (A) with water. For this, pour approx. 0.3 l of water into the combustion chamber.
7. Check that condensate can drain freely and that the connections are tight.

Further details regarding the individual steps (cont.)

Burner installation



1. Mount burner and secure with four screws (A).
2. Insert new gasket and tighten the fittings on gas supply pipe (B).
3. Tighten four screws (A) diagonally with 8.5 Nm.
4. Fit electrical cables to fan motor (D), gas valve (E) and ignition unit (F).
5. Reopen gas supply and switch ON power supply.

Further details regarding the individual steps (cont.)

6. Check the gas connections for tightness.
7. Push grommet © up again.



Danger

Escaping gas leads to a risk of explosion.
Check all fittings for gas tightness.



Please note


The use of leak detection spray can result in incorrect function.
Leak detection spray must not reach electrical contacts or seal diaphragm openings on the gas valve.

Further details regarding the individual steps (cont.)

Checking the diaphragm expansion vessel and system pressure

Carry out this check with a cold system.

1. Drain the system, until the pressure gauge indicates "0".
2. If the pre-charge pressure of the diaphragm expansion vessel is lower than the static system pressure, top up with nitrogen until the pre-charge pressure is raised by 0.1 to 0.2 bar.
3. Top up with water until the charge pressure of the cooled system is at least 1.0 bar and 0.1 to 0.2 bar higher than the pre-charge pressure of the diaphragm expansion vessel.
Permiss. operating pressure: 3 bar



(A) Test port

Checking gas equipment for tightness at operating pressure



Danger

Escaping gas leads to a risk of explosion.
Check gas equipment for tightness.




Please note

The use of leak detection spray can result in incorrect function. Leak detection spray must not reach electrical contacts or seal diaphragm openings on the gas valve.

Further details regarding the individual steps (cont.)

Fitting the front panel




1. Hook the front panel into place.

2. Tighten screws at the bottom.


Instructing the system user

The system installer must hand the operating instructions to the system user and instruct the user in operating the system.


Function sequence and possible faults



Function sequence and possible faults (cont.)



Fault messages on the display



Faults are indicated by a flashing fault code with fault symbol "I" on the display.

For fault code explanations see the following table.

Displayed fault code	System characteristics	Cause	Measures
0C	Burner blocked	Mains voltage too low	Check power supply.
10	Constant mode	Short circuit, outside temperature sensor	Check the outside temperature sensor and lead (see page 44).
18	Constant mode	Lead break, outside temperature sensor	Check the outside temperature sensor and lead (see page 44).
30	Burner blocked	Short circuit, boiler water temperature sensor	Check the boiler water temperature sensor (see page 45).
38	Burner blocked	Lead break, boiler water temperature sensor	Check the boiler water temperature sensor (see page 45).
50	No DHW heating	Short circuit, cylinder temperature sensor	Check the sensor (see page 46).

Fault messages on the display (cont.)

Displayed fault code	System characteristics	Cause	Measures
51	No DHW heating	Short circuit, outlet temperature sensor	Check the sensor (see page 47).
58	No DHW heating	Lead break, cylinder temperature sensor	Check the sensor (see page 46).
59	No DHW heating	Lead break, outlet temperature sensor	Check the sensor (see page 47).
A9	Control mode without OpenTherm device	Communication error, OpenTherm device	Check connections and lead; replace OpenTherm device if required.
b0	Burner blocked	Short circuit, flue gas temperature sensor	Check the sensor (see page 49).
b8	Burner blocked	Lead break, flue gas temperature sensor	Check the sensor (see page 49).
E3	Burner in a fault state	Fault in safety chain.	Check the temperature limiter and connecting leads (see page 48). Check the control unit, and replace if required.
E5	Burner blocked	Internal fault	Check the ignition/ionisation electrode and connecting cables. Press "Reset" (see page 42).
F0	Burner blocked	Internal fault	Replace control unit.
F1	Burner in a fault state	Max. flue gas temperature exceeded	Check heating system fill level. Check circulation pump. Vent the system. Press "Reset" (see page 42).


Fault messages on the display (cont.)

Displayed fault code	System characteristics	Cause	Measures
F2	Burner in a fault state	The temperature limiter has responded	Check heating system fill level. Check circulation pump. Vent the system. Check the temperature limiter and connecting leads (see page 48). Press "Reset" (see page 42).
F3	Burner in a fault state	Flame signal is already present at burner start	Check ionisation electrode and connecting cables. Press "Reset" (see page 42).
F4	Burner in a fault state	No flame signal	Check the ignition/ionisation electrode and connecting cables, check the gas pressure, check the gas train, ignition and condensate drain. Press "Reset" (see page 42).
F8	Burner in a fault state	Fuel valve closes too late	Check gas train. Check both control paths. Press "Reset" (see page 42).
F9	Burner in a fault state	Fan speed too low during burner start	Check fan, fan connecting cables and power supply; check fan control. Press "Reset" (see page 42).
FA	Burner in a fault state	Fan not at standstill	Check fan, fan connecting cables and fan control. Press "Reset" (see page 42).
FC	Burner blocked	Electrical fan control (control unit) faulty	Check fan connecting cable; if required, replace or replace control unit.

Fault messages on the display (cont.)

Displayed fault code	System characteristics	Cause	Measures
Fd	Burner blocked	Fault, burner control unit	Check ignition electrodes and connecting cables. Check whether a strong interference (EMC) field exists near the appliance. Press "Reset" (see page 42). Replace control unit if fault persists.
FF	Burner blocked	Fault, burner control unit	Check ignition electrodes and connecting cables. Check whether a strong interference (EMC) field exists near the appliance. Press "Reset" (see page 42). Replace control unit if fault persists.


Press reset



Turn rotary selector "III 🔥" to "I RESET", until **"SERV"** is shown.
Within 2 s return the rotary selector to the control range.

Repairs

Removing the front panel




1. Undo screws at the bottom of the boiler; do not remove completely.


2. Remove front panel.

Repairs (cont.)

Outside temperature sensor




1. Open the control unit casing. See page 15.
2. Disconnect leads from outside temperature sensor.




3. Check the sensor resistance and compare it with the curve.
4. Replace the sensor in the case of severe deviation.

Repairs (cont.)

Boiler water temperature sensor



1. Pull the leads from boiler water temperature sensor (A) and check the resistance.



2. Check the sensor resistance and compare it with the curve.
3. In the case of severe deviation, drain the boiler on the heating water side and replace the sensor.




Danger

The boiler water temperature sensor is immersed in the heating water (risk of scalding).


Drain the boiler before replacing the sensor.

Repairs (cont.)

Checking cylinder temperature sensor



1. Pull plug **5** from the cable harness.





2. Check the sensor resistance and compare it with the curve.

3. Replace the sensor in the case of severe deviation.

Repairs (cont.)

Checking the outlet temperature sensor



1. Pull leads from outlet temperature sensor (A).
2. Check the sensor resistance and compare it with the curve.
3. Replace the sensor in the case of severe deviation.



Danger


The outlet temperature sensor is immersed in the DHW (risk of scalding). Drain the DHW side of the boiler before replacing the sensor.

Sensor type: NTC 10 kΩ

Repairs (cont.)

Checking the temperature limiter


If the burner control unit cannot be reset after a fault shutdown, although the boiler water temperature is below approx. 95 °C, check the temperature limiter.




1. Pull the leads from temperature limiter (A).
2. Check the continuity of the temperature limiter with a multimeter.
3. Remove the faulty temperature limiter.
4. Install a new temperature limiter.
5. Press "Reset" at the control unit (see page 42).

Repairs (cont.)

Checking the flue gas temperature sensor



1. Pull leads from flue gas temperature sensor (A).




2. Check the sensor resistance and compare it with the curve.
3. Replace the sensor in the case of severe deviation.

Repairs (cont.)

Checking and cleaning the plate heat exchanger

Note


Drain the boiler on its heating water and DHW side.



1. Undo plate heat exchanger (A) (screws (B)) and pull away from the front.
2. Check the connections on the heating water and DHW side for contamination and scaling; if required, replace the plate heat exchanger.
3. Install in reverse order with new gas-kets.

Repairs (cont.)


Checking the fuse



1. Switch off the power.
2. Open control unit casing (see page 15).
3. Check fuse F4.

Converting from LPG to natural gas

Removing gas restrictor



2. Pull cable from gas train (A).
3. Undo two screws (B) and remove gas train (A).
4. Remove gas restrictor (C) from gas train (A).
5. Mount gas train (A) with new gasket (D).
Torque for fixing screws (B): 3 Nm.
6. Refit the burner with new gasket (E).
7. Remove or void gas type sticker on the top of the boiler (next to the type plate).
8. Fitting the burner (see "Commissioning, inspection and maintenance")
9. Start the boiler and check for leaks.



Danger




Escaping gas leads to a risk of explosion.
Check gas equipment for tightness.

1. Removing the burner (see "Commissioning, inspection and maintenance")

Converting the gas type at the control unit

1. Switch on the ON/OFF switch.

Converting from LPG to natural gas (cont.)



2. Turn both rotary selectors "flame icon" and "flame icon" simultaneously to their respective central positions.

"SERV" appears on the display.

3. Turn rotary selector "flame icon" within 2 s fully anticlockwise. The display shows "flame icon" and the set value flashes.

4. Adjust the control unit to natural gas or LPG by turning rotary selector "flame icon".

The display shows:

- "0" for operation with natural gas or
- "1" for operation with LPG.

5. The set operating mode is saved when the value stops flashing, and the control unit returns to standard mode.

Checking the CO₂ content


See "Commissioning, inspection and maintenance".

Functions and operating conditions in weather-compensated mode

Heating mode

In weather-compensated mode, the boiler water temperature is regulated subject to the outside temperature.

Heating curve of weather-compensated control unit



Setting of rotary selector "🌡️📊"

- (A) = 1
- (B) = 2
- (C) = 3
- (D) = 4
- (E) = delivered condition
- (F) = 5
- (G) = 6

Frost protection function

Frost protection function is only possible when an outside temperature sensor is connected. Frost protection function is active at outside temperatures of $< 5^{\circ}\text{C}$. The burner starts and the boiler water temperature is held at 20°C .

Functions and operating conditions in... (cont.)

DHW heating

Heating the DHW primary store from cold

The heating circuit pump is switched on and the 3-way diverter valve will be changed over, if the cylinder temperature sensor captures a temperature lower than the default set value.

- The cylinder primary pump is switched on if the boiler water temperature $\geq$ set DHW temperature.
- The burner is switched on if the boiler water temperature $\leq$ set DHW temperature, and the cylinder primary pump is switched on when the required boiler water temperature is reached.

The primary store is heated up to the set DHW temperature. Heating stops when the specified temperature has been reached at the cylinder temperature sensor.

After heating, the cylinder primary pump and the 3-way diverter valve remain on for a further 30 s.

- The cylinder primary pump is switched on if the boiler water temperature $\geq$ set DHW temperature.
- The burner is switched on if the boiler water temperature $\leq$ set DHW temperature, and the cylinder primary pump is switched on when the required boiler water temperature is reached.

DHW is regulated to the set temperature via the outlet temperature sensor.

The primary store continues to be heated up after the draw off process has terminated, until the set DHW temperature has been reached at the cylinder temperature sensor.


The cylinder primary pump and the 3-way diverter valve remain on for a further 30 s.

Reheating when DHW is drawn off

When DHW is drawn off, cold water enters at the bottom of the primary store.

The heating circuit pump is switched on and the 3-way diverter valve is changed over, if the cylinder temperature sensor recognises a temperature lower than the set value.

Connection and wiring diagram



Connection and wiring diagram (cont.)

Ⓒ	Vitotrol 100	X ...	Electrical interface
	■ Type RT	3	Boiler water temperature sensor
	■ Type UTA	4	Outlet temperature sensor (gas condensing combi boiler)
	■ type UTDB	5	Cylinder temperature sensor (gas condensing boiler)
	■ Type UTDB-RF	15	Flue gas temperature sensor
Ⓓ	Power input 230 V/50 Hz	20	Circulation pump (heating water)
Ⓔ	Remote control (Open Therm device)	21	Cylinder primary pump
Ⓕ	Outside temperature sensor (accessory)	35	Gas solenoid valve
Ⓖ	Time switch (accessory)	47	Temperature limiter
Ⓕ	Gas pressure switch (accessory)	100	Fan motor 230 V~
		100A	Fan control







Ordering parts

The following information is required:

- Serial no. (see type plate (A))
- Assembly (from this parts list)
- Position number of the individual part within the assembly (from this parts list)

Standard parts are available from your local supplier.

Overview of the assemblies



- (A) Type plate (on the cover panel)
 (B) Casing assembly
 (C) Heat cell assembly


- (D) Hydraulic assembly
 (E) Control unit assembly
 (F) Miscellaneous assembly

Overview of the assemblies (cont.)

Ⓔ Cylinder assembly

Casing assembly


- | | | | |
|------|-------------------------|------|----------------------------|
| 0001 | Front panel | 0007 | Toggle fastener (set) |
| 0002 | Logo | 0008 | Pipe clip Ø 18 |
| 0003 | Cover panel with gasket | 0012 | Air box gasket, gas pipe |
| 0004 | Profiled seal | 0013 | Wall mounting bracket |
| 0005 | Control unit support | 0014 | Diaphragm grommets (5 pce) |
| 0006 | Safety guard | | |



Heat cell assembly

0001	Gasket DN 60	0009	Condensate hose
0002	Boiler flue connection	0010	Splash siphon
0003	Boiler flue connection plug	0013	Condensate hose
0004	Flue gas gasket	0015	Gas supply pipe
0005	Flue gas temperature sensor	0016	Gasket 17 x 24 x 2 (set)
0006	Heat exchanger	0019	Burner
0007	Thermal insulation block	0020	Tee
0008	Moulded hose heating water return	0021	Hose 19 x 600 mm, corrugated
		0023	Hose clip DN 25


Heat cell assembly (cont.)



Burner assembly

0001	Burner gasket	0009	Radial fan
0002	Thermal insulation ring	0010	Gas valve
0003	Cylinder burner gauze assembly	0012	Venturi extension
0004	Burner gauze assembly gasket	0013	Gaskets (set)
0005	Burner door	0014	Conversion kit G31
0006	Ionisation electrode gasket	0015	Gasket set G27
0007	Ignition and ionisation electrode	0016	Conversion kit G2.350/G27
0008	Burner door flange gasket		


Burner assembly (cont.)



Hydraulic assembly


0001	Temperature sensor	0028	Clip Ø 10 (5 pce)
0002	Thermal circuit breaker	0029	Return pipe
0003	Air vent valve G ¾	0030	Safety valve
0004	Hose Ø 10 x 1.5 x 750	0031	Condensate hose
0005	Clip Ø 8 (5 pce)	0032	Circulation pump UPS 60 (19 - 26 kW)
0006	Heat exchanger connection pipe	0033	Quick-action air vent valve
0007	O-ring gasket set 17.86 x 2.62	0034	Circulation pump motor UPS 60 (19 - 26 kW)
0008	Hose clip DN 25	0035	Circulation pump UPS 70 (35 kW)
0009	Hose connector adaptor	0036	Circulation pump motor UPS 70 (35 kW)
0010	Clip Ø 18 (5 pce)	0037	Heating water return connection pipe
0011	Diaphragm grommet	0038	Diaphragm expansion vessel
0012	Gasket set A 17 x 24 x 2	0039	Hose clip Ø 220-240 x 9
0013	Heating water flow connection pipe	0040	Gasket A 10 x 15 x 1.5 (set)
0014	Pressure gauge	0041	Connection line; diaphragm expansion vessel
0015	O-ring gasket set 9.6 x 2.4	0042	Aqua-plate
0017	O-ring 14.3 x 2.4	0043	Connection pipe, heating water filling
0018	Clip Ø 15 (5 pce)	0044	Connection pipe, filling loop, potable water
0019	Connection pipe, circulation pump	0045	Gasket A 6 x 11 x 1
0020	Gasket 23 x 30 x 2	0046	Fill valve
0021	Circulation pump VIUP-30	0051	Plug Ø 8/10
0022	Circulation pump motor VIUP-30		
0023	Support, cylinder primary pump		
0024	Connection pipe, cold water		
0025	Connection manifold, cold water		
0026	Flat gasket		
0027	Round gasket 8 x 2		

Hydraulic assembly (cont.)



Aqua plate assembly


- | | |
|---------------------------|--|
| 0001 Valve insert | 0008 Temperature sensor |
| 0002 Flow unit | 0009 Clip Ø 8 (5 pce) |
| 0003 Return unit | 0010 Clip Ø 10 (5 pce) |
| 0004 Overflow valve | 0011 Pipe clip Ø 18 (5 pce) |
| 0005 Overflow pipe | 0012 Gasket A 17 x 24 x 2 (set) |
| 0006 Plate heat exchanger | 0013 Gasket, O-ring 17.86 x 2.62 (set) |
| 0007 Profiled gasket | |



Control unit assembly

0001	Control unit	0006	Cable harness stepper motor
0002	Cover, wiring chamber	0007	Ignition cable with angled plug
0003	Fuse 2.5 A (slow) 250 V		5 k Ω
0004	Cable harness X20	0008	Cable fixing
0005	Cable harness 100/35		

Control unit assembly (cont.)




5618 689 UAE

Cylinder assembly

0001	O-ring 14.3 x 2.4 (set)	0008	Protective profile
0002	Clip Ø 15 (5 pce)	0009	Hose clip Ø 340 - 360 x 9
0003	DHW connection pipe	0010	Cylinder
0004	Non-return valve (cartridge)	0011	Thermal insulation EPS, front
0005	Shut-off elbow, cylinder	0012	Thermal insulation EPS, back
0006	DHW connection pipe	0014	Strain relief
0007	Flat gasket	0015	Cylinder temperature sensor NTC

Cylinder assembly (cont.)



Miscellaneous assembly


0001 Special grease
0002 Touch-up spray paint, white

0003 Touch-up paint stick, white

Miscellaneous assembly (cont.)

0004 Installation and service instructions

0005 Operating instructions



Specification

Rated voltage:	230 V~	Temperature limiter	
Rated frequency:	50 Hz	setting:	100 °C (fixed)
Rated current:	2.0 A~	Backup fuse (power	
Safety category:	I	supply):	max. 16 A
IP rating:	IP X4D to EN 60529		

Permissible ambient temperature

- during operation: 0 to +40 °C
- during storage and transport: -20 to +65 °C

Rated heating output range in heating mode				
T_V/T_R 50/30 °C	kW	6.5 – 19	6.5 – 26	8.8 – 35
T_V/T_R 80/60 °C	kW	5.9 – 17.3	5.9 – 23.7	8.0 – 31.9
Rated heating output range for DHW heating	kW	5.9 – 24.0	5.9 – 29.3	8.0 – 35.0
Rated heat input range	kW	6.1 – 24.7	6.1 – 30.5	8.2 – 36.5
Connection values				
relative to the max. load with:				
- Natural gas E	m ³ /h	2.61	3.23	3.86
- LPG P	kg/h	1.94	2.39	2.86
Power consumption (max.)	W	140	160	185
Product ID	CE-0085BT0029			

Note

The connection values are only for documentation purposes (e.g. in the gas contract application) or to estimate a supplementary volumetric settings check. Due to the factory settings, the gas pressure must not be altered from these values. Reference: 15°C, 1013 mbar.

Declaration of conformity

Declaration of Conformity for the Vitodens 111-W

We, Viessmann Werke GmbH&Co KG, D-35107 Allendorf, confirm as sole responsible body that the product **Vitodens 111-W** complies with the following standards:

DIN 4753	EN 55 014-1
EN 297	EN 55 014-2
EN 483	EN 60 335-1
EN 625	EN 60 335-2-102
EN 677	EN 61 000-3-2
EN 806	EN 61 000-3-3
EN 12 897	EN 62 223

In accordance with the following Directives, this product is designated with **CE-0085**:

92/42/EEC	2006/95/EG
2004/108/EG	2009/142/EG

This product complies with the requirements of the Efficiency Directive (92/42/EEC) for **condensing boilers**.

Allendorf, 01 March 2012

Viessmann Werke GmbH&Co KG



Authorised signatory Manfred Sommer

Keyword index

B

Boiler water temperature sensor	45
Burner gasket.....	30
Burner gauze assembly.....	30
Burner installation.....	34
Burner removal.....	29

C

Cleaning the combustion chamber...32	
Cleaning the heat exchanger.....	32
Cold water connection.....	7
Commissioning.....	20
Condensate.....	13
Condensate drain.....	13, 33
Connection diagram.....	56
Connections.....	7, 10
Connections on the water side.....	10
Cylinder temperature sensor	46

D

Declaration of Conformity.....	74
DHW connection.....	7
Draining.....	7

E

Electrical connections.....	15
-----------------------------	----

F

Fault code.....	39
Fault messages.....	39
Filling.....	7
Filling function.....	20
Filling the system.....	20, 21
Flue gas temperature sensor.....	49
Flue pipe.....	14
Frost limit.....	54
Frost protection.....	54
Function sequence.....	38
Fuse.....	51

G

Gas connection.....	7, 11
Gas type conversion	52
■ LPG.....	23
■ Natural gas.....	52

H

Heating curve.....	54
Heating flow.....	7
Heating return.....	7

I

Ignition.....	31
Ignition electrode.....	31
Ionisation electrode.....	31

M

Max. heating output.....	24
--------------------------	----

O

Opening the control unit.....	15
Outlet temperature sensor.....	47
Output matching	
■ Flue pipe length.....	23
Outside temperature sensor	44

P

Plate heat exchanger.....	50
Power supply.....	17

R

Reducing the heating output.....	24
Reset.....	42

S

Safety chain	48
Safety valve.....	7, 13
Siphon.....	13, 33
Specification	73
System pressure.....	21

Keyword index (cont.)

T

Temperature limiter.....	48
Troubleshooting.....	43

V

Ventilation air pipe.....	14
Venting.....	22

W

Wall mounting.....	9
Weather-compensated mode.....	54

Applicability

Serial No.:

7487555	7499472	7499473	7499474
7499475	7499476	7499477	7499478
7499479	7499480	7499481	

Viessmann Middle East FZE
E-Wing, Office 603
HQ Building
Dubai Silicon Oasis
PO Box 341330
Dubai, UAE
Tel: +971 4 3724240
Fax: +971 4 3724241

Viessmann Werke GmbH&Co KG
D-35107 Allendorf
Telephone: +49 6452 70-0
Fax: +49 6452 70-2780
www.viessmann.com